

# MAXIM

## MAX2420 Evaluation Kit

Evaluates: MAX2420

### General Description

The MAX2420 evaluation kit (EV kit) simplifies evaluation of the MAX2420 900MHz image-reject transceiver.

The EV kit provides 50Ω SMA connectors for all RF inputs and outputs. A varactor-based tank circuit is provided for the MAX2420 VCO and can be tuned by a potentiometer or external voltage. The VCO can be overdriven by an external source, if desired.

Switches are provided to control power-management features.

### Ordering Information

| PART            | TEMP. RANGE    | BOARD TYPE    |
|-----------------|----------------|---------------|
| MAX2420EVKIT-SO | -40°C to +85°C | Surface Mount |

### Features

- ♦ 50Ω SMA Ports for Testing Transmit and Receive Paths
- ♦ SMA Port for Prescaler Output
- ♦ Switches Included to Control Power-Management Features
- ♦ VCO Frequency, Receiver Gain, and Transmitter Gain Adjustable via On-Board Potentiometers or External Inputs
- ♦ Fully Assembled and Tested

### Component List

| DESIGNATION   | QTY | DESCRIPTION   |
|---|-----|---|
| C1, C4, C5, C7, C9, C10, C12, C15, C19, C21–C24, C28, C32 | 15  | 47pF ceramic capacitors   |
| C2, C3  | 2   | 10pF ceramic capacitors   |
| C6, C14   | 2   | 0.1μF ceramic capacitors  |
| C8, C11, C13, C20, C25, C29, C30, C31                     | 8   | 0.01μF ceramic capacitors   |
| C16   | 1   | 1000pF ceramic capacitor  |
| C17, C18  | 2   | 10μF, ±10%, 10V tantalum capacitors AVX TAJB106K010 or Sprague 2930106X90010B |
| C27   | 0   | Not installed   |
| D1  | 1   | Dual-varactor diode Alpha SMV1204-199   |
| JU2, JU3, JU4, JU7, JU8                                   | 5   | Shunts  |
| JU2, JU3, JU4, JU7, JU8, GND, VEXT, DGND                  | 8   | 2-pin headers   |
| L1  | 1   | 22nH inductor Coilcraft 0805CS-220XMBC  |
| L2  | 1   | 8.2nH inductor Coilcraft 0805CS-080XMBC                                       |
| L3  | 1   | 8.2nH inductor Toko LL2012-F8N2K  |

| DESIGNATION                                    | QTY | DESCRIPTION                             |
|--|-----|---|
| L4   | 1   | 100nH inductor Coilcraft 0805CS-101XKBC |
| L5, L7   | 0   | Not installed                           |
| L6   | 1   | 12nH inductor Coilcraft 0805CS-120XMBC  |
| L8   | 1   | 18nH inductor Coilcraft 0805CS-180XMBC  |
| L9   | 1   | 82nH inductor Coilcraft 0805CS-820XKBC  |
| LNAGAIN, TXGAIN, VCOADJ                        | 3   | 1-pin headers                           |
| R1, R2, R3                                     | 3   | 10kΩ potentiometers                     |
| R4, R5   | 2   | 1kΩ, 5% resistors                       |
| R6, R7   | 2   | 10Ω, 5% resistors                       |
| R8   | 1   | 47kΩ, 5% resistor                       |
| R9, R14–R17                                    | 5   | 10kΩ, 1% resistors                      |
| R10, R13                                       | 2   | Not installed                           |
| R12, R19                                       | 2   | 301Ω, 1% resistors                      |
| R18, R20                                       | 2   | 49.9Ω, 1% resistors                     |
| RXIN, RXOUT, TXOUT, TXIN, PREOUT, EXT LO INPUT | 6   | SMA connectors (PC edge mount)          |
| SW1  | 1   | 5-position dip switch                   |
| U1   | 1   | MAX2420EAI 28SSOP                       |



Maxim Integrated Products 1

For free samples & the latest literature: <http://www.maxim-ic.com>, or phone 1-800-998-8800.  
For small orders, phone 408-737-7600 ext. 3468.

# MAX2420 Evaluation Kit

## Component Suppliers

| SUPPLIER*        | PHONE          | FAX            |
|------------------|----------------|----------------|
| Alpha Industries | (617) 935-5150 | (617) 933-2359 |
| AVX              | (803) 946-0690 | (803) 626-3123 |
| Coilcraft        | (847) 639-6400 | (847) 639-1469 |
| Sprague          | (603) 224-1961 | (603) 224-1430 |

\*Please indicate that you are using the MAX2420 when contacting these component suppliers.

## Quick Start

The MAX2420 EV kit is fully assembled and factory tested. **Do not turn on the DC power and signal sources until all connections are made.**

### Test Equipment Required

- RF-signal generator capable of generating frequencies up to 1GHz
- Spectrum analyzer with frequency range at least to 3GHz, such as the HP8561
- Power supply capable of +2.7V to +5.5V output at 100mA

### Connections and Signal Conditions

- 1) Verify that all shunts are installed across jumpers JU2, JU3, JU4, JU7, and JU8.
- 2) Verify that switch positions 1 through 5 on SW1 are set at the "logic 0" position.
- 3) Set the power supply to 3.3V, and set the current limit to 100mA.
- 4) Connect the power supply to the VEXT and GND terminals on the EV kit.
- 5) For testing the receive path, set the signal-source frequency to 915MHz and the power level to -35dBm. For testing the transmit path, set the signal-source frequency to 10.7MHz and the power level to -0.8dBm.

### Analysis

- 1) Turn on the on-chip oscillator by setting switch VCOON to "logic 1." To observe the VCO frequency, set switch DIV 1 to "logic 1" (disabling the prescaler and enabling the buffer amplifier) and connect an SMA cable from the spectrum analyzer to the PREOUT port. Set the VCO frequency to 925.7MHz by adjusting VCOADJ (R3). The VCO tuning range is typically 180MHz and may vary slightly due to tolerances in the varactor diodes.

- 2) The receive conversion gain can be evaluated by setting switch RXON to "logic 1," applying a 915MHz signal to the RXIN port, and observing the RXOUT port at 10.7MHz with the spectrum analyzer. The gain of the LNA in the receiver path can be adjusted by varying R2.

**Note:** R12 and R18 are used as a resistive matching network to present an optimum 330Ω impedance to the RXOUT pin. This network results in a 14.2dB loss in the receiver path. Therefore, 14.2dB must be added to the power level observed on the spectrum analyzer to obtain the true receive output power. For example, with LNAGAIN set at VCC and the receive input level set at -35dBm, the receive output observed on the spectrum analyzer is approximately -27.2dBm. The true receive conversion gain is  $-27.2 - (-35) + 14.2 = 22\text{dB}$ .

If desired, pads for C8, R18, C30, R12, L5, and C20 can be used to build a custom reactive-matching network.

- 3) Receive image rejection can be evaluated by changing the receive input frequency to 936.4MHz (while keeping the LO at 925.7MHz) and comparing the output signal level against the one measured in step 2.
- 4) Before evaluating the transmitter, ensure that the receiver is disabled by setting switch RXON to "logic 0." The transmit conversion gain can be evaluated by setting switch TXON to "logic 1", applying a 10.7MHz signal at -0.8dBm to the TXIN port, and observing the TXOUT port at 915MHz with a spectrum analyzer. The gain of the input buffer amp in the transmit path can be adjusted by varying R1.

**Note:** R19 and R20 are used as a resistive matching network to present an optimum 330Ω impedance to the TXIN pin. This network results in a 14.2dB loss in the transmit path. Therefore, 14.2dB must be subtracted from the signal source's power to obtain the input power applied to the MAX2420 (-15dBm). With TXGAIN set at 2V and the transmit input level set at -0.8dBm, the transmit output observed on the spectrum analyzer is approximately -4dBm. The transmit conversion gain is  $-4 - (-15) = 11\text{dB}$ .

If desired, pads for R19, R20, C11, L7, and C25 can be used to build a custom reactive-matching network.

- 5) Tx image rejection can be evaluated by comparing the desired lower sideband at 915MHz against the unwanted upper sideband at 936.4MHz.

# MAX2420 Evaluation Kit

## Adjustments and Control

### VCOADJ

The VCO frequency can be tuned by adjusting on-board potentiometer R3. It can also be tuned by first removing the shunt from jumper JU7 and then applying an external voltage via the VCO ADJ terminal. The supply providing the external voltage must be properly bypassed to minimize noise added to the LO.

### LNAGAIN

The LNA gain can be adjusted using on-board potentiometer R2. LNA gain control can also be accomplished by first removing the shunt from jumper JU2 and then applying an external voltage via the LNA GAIN terminal.

### TXGAIN

The transmit buffer amp gain can be adjusted using on-board potentiometer R1. Transmit gain control can also be accomplished by first removing the shunt from jumper JU3 and then applying an external voltage via the TXGAIN terminal.

### RXON and TXON

The receive and transmit sections are enabled by setting switches RXON and TXON to "logic 1," respectively. Since the transmit and receive sections share an LO and an IF frequency, interference will result if both sections are active at the same time. When testing either the receive or transmit section, always disable the other section.

To disable all chip functions, set all switches to "logic 0." To obtain an accurate reading of the device shutdown current, remove the shunt from JU4 and move the VCC connection from the VEXT terminal to the left side of JU4.

## Prescaler Control

The function of PREOUT is controlled by the switches labeled "DIV1" and "64" (Table 1).

**Table 1. PREOUT Function Control Switches**

| PREOUT<br>FUNCTION   | SWITCH POSITIONS |            |
|----------------------|------------------|------------|
|                      | DIV1             | 64         |
| LO buffered output   | Logic 1          | Don't care |
| Prescaler, $\div 64$ | Logic 0          | Logic 1    |
| Prescaler, $\div 65$ | Logic 0          | Logic 0    |

## Layout Considerations

The MAX2420 EV board can serve as a guide for your board layout. Take care in laying out the oscillator tank circuit. Oscillation frequency is sensitive to parasitic PC board capacitance, trace inductance, and package inductance. Keep the tank layout as symmetrical, tightly packed, and close to the device as possible to minimize LO feedthrough. When using a PC board with a ground plane, a cutout in the ground plane below the oscillator tank reduces parasitic capacitance. Also, keep traces carrying the receive and transmit signals as short as possible to minimize radiation and insertion loss due to the PC board.

Evaluates: MAX2420

# MAX2420 Evaluation Kit





Figure 1. MAX2420 EV Kit Schematic

Evaluates: MAX2420



# MAX2420 Evaluation Kit

Evaluates: MAX2420




Figure 4. MAX2420 EV Kit PC Board Layout—Ground Plane




Figure 5. MAX2420 EV Kit PC Board Layout—Power Plane

## MAX2420 Evaluation Kit

Evaluates: MAX2420




Figure 6. MAX2420 EV Kit PC Board Layout—Solder Side

# MAX2420 Evaluation Kit

## NOTES

Maxim cannot assume responsibility for use of any circuitry other than circuitry entirely embodied in a Maxim product. No circuit patent licenses are implied. Maxim reserves the right to change the circuitry and specifications without notice at any time.

8 \_\_\_\_\_ Maxim Integrated Products, 120 San Gabriel Drive, Sunnyvale, CA 94086 408-737-7600

© 1997 Maxim Integrated Products Printed USA  is a registered trademark of Maxim Integrated Products.