

Single axis controller SS 22 Spare parts


4/206 2002



The spindle block Pos. 1 incorporates an internal gearing, control-handle with knob solid, bellow and ring nut.

By all spare part orders it is nessesary to inform us about the Work-No. (7 characters) on the switch gear.

Spindle block with schematic representation of the master controller installation and deflection directions. Version shown for left hand side installation (right-hand side installation is mirror image).



Deflection directions designated to DIN 15025

Pos.	SS 22	Drawing No.	Туре	Weight gramm	Price EURO
1	1		SS 22	600	
2					
3	1-2				
4	2				
5	2				
10					
11					
12	Spring return in 0-position	KMFD/58	Z	20	
13	Friction brake	KHS/167	R	20	
14					
20	Control-handle with knob solid with joint	KHS/507		50	
21	Control-handle with latch for mechanical zero interlock with joint	KHS/506	M	50	
22	Control-handle with dead man's button (mechanical parts) with joint	KHS/508	Т	100	
23	Control-handle with signal button (mechanical parts) with joint	KHS/505	Н	100	
24	Control-handle with push button (mechanical parts) with joint	KHS/504	D	110	
25	Control-handle with flat push button (mechanical parts) with joint	KHS/646		110	
26	Control-handle with palm grip B 5 with joint	KBAD/254		40	
27	Control-handle with palm grip B 5 with push button top (mechanical parts) with joint	KBAD/311	B 5T	60	
28	Control-handle long or short 140, 100 mm				
29	More knobs, grips and T-grips with and without signal devices look catalog 1/228				
41	Prepared for mounting potentiometer shaft 6 mm adjusting angle 2 x 150°	KHS/400	(P)		
42	Prepared for mounting potentiometer e.t.c. adjusting angle variable		(P)		
43	More potentiometer e.t.c. look catalog 1/240				
80	Bellows	KMD 20			
81	Ring nut (for mounting the bellow)	KMS 463			
82	Gasket (for spindle block Pos. 1)	KMD 33			
83	Gasket cap (for push button Pos. 24)				
84	Knob solid (for Pos. 20)	KBAD 66			
85	Knob-type with shaft activities (for Pos. 21-25, 1 Pos. only)				
86	Spare gear with cam shaft (for Pos. 20-27)	KHS/400			
87 88	Notching (1 notching lever/notching disk with roll, 1 notching spring)				
89					
90	Microswitch (166) 2 A 250 V AC 15 with roll-lever and insulating disk (for master switch)				
91	Microswitch (166) 2 A 250 V AC 15 with roll-lever, 2 insulating disk and contact striker				
´'	(for Pos. 22, 23, 24, 27)				
	(3 33. 22, 20, 21, 21)				