

Distribute and extend component video and audio

Related Products

Extend up to 4 sets of Component A/V -- up to 1000 feet!

1:4 Component Audio CAT5 Distribution Amplifier



The 1:4 Component/Audio over CAT5 Distribution Amplifier sends up to 4 identical sets of sparkling clear component video and associated audio up to 1080p at remote locations via four CAT5 cables -- at distances of up to 1000 feet. Now you can reliably and cleanly distribute up to four copies of a video signal and accompanying digital or analog audio to remote locations without having to worry about signal drop-off and loss of quality.

How It Works

Simply plug in your component video and audio from your source to the 1:4 Component/Audio D.A. Sender. Your audio can be analog, SPDIF or TOSlink. Run your lengths of CAT5 cable from the Sender box through your building to up to 4 remote destinations. Connect each Receiver box to its CAT5 cable. Attach the Receivers to your displays, turn on all equipment, and you should see beautiful video extended and duplicated at up to four locations. All audio ports on the CAT5 Descine with the Receivers duplicated at up to four locations. All audio ports on the CAT5 Descine with the Receivers of the prevented by the duplicated and a set of the cable. Attach the Receivers of the set of the prevented by the prevented by the set of the prevented by the set of the prevented by the set of the prevented by th Receiver will also be active, so even if your source only had analog audio your Component Audio Receiver will have digital and analog audio output.

Note: You will need 1 Component Audio Receiver for each remote location (Sold separately).

Features:

- Supports up to 1080p component video
 Supports analog L+R audio and multichannel digital TOSLink or S/PDIF
- No Loss of QualityPlug and play installation
- Equalizations for different CAT-5 skews ٠
- One CAT-5 cable for extension

Specifications:

- Video Amplifier Bandwidth: 350 MHz

- Video Amplifier Bandwidth: 350 MHz
 Input Video Signal: 1.2 Volts p-p
 Input Sync Signal: 5 Volts p-p (TTL)
 Horizontal Frequency Range: 15-70 KHz
 Vertical Frequency Range: 30-170 Hz
 Video In/Out: 3 RCA component
 Audio In/Out: 2 RCA Audio, 1 SPDIF, 1 TOSlink
 Link Connector: RJ-45 Shielded
 Perwer Sumply: 5 D C
- Power Supply: 5V DC
 Dimensions: 8.5"W x 1.6"H x 4.25"D

Package Includes:

- One 1:4 Component Audio CAT5 Sender
- One 5V DC Power Supply
 One Component cable
 One RCA Cable
- One Users Manual

Product Options:

- How Many Component Receivers do you need? 1 x EXT-COMPAUD-141R (\$200.00) 2 x EXT-COMPAUD-141R (\$400.00) 3 x EXT-COMPAUD-141R (\$600.00)

- 4x EXT-COMPAUD-141R (\$800.00)



EXT-COMPAUD-CAT5-144



Dystrybucja i sprzedaż: Meditronik Sp. z o.o. 02-952 Warszawa, ul. Wiertnicza 129, tel. (+48 22) 651-72-42, fax (+48 22) 651-72-46

1:4 Component/ Audio Over CAT5 Distribution Amplifier

befen

Model EXT-COMPAUD-CAT5-144

USER MANUAL

Gefen

COMPONENTw/Audio

1.4 COMPONENT/Audio over CAT-5 DA

www.gefen.com

Technical Support:

Telephone	(818) 772-9100
	(800) 545-6900

Fax (818) 772-9120

Technical Support Hours:

8:00 AM to 5:00 PM Monday through Friday PST

Write To:

Gefen Inc. C/O Customer Service 20600 Nordhoff St. Chatsworth, CA 91311

support@gefen.com www.gefen.com

Notice

Gefen Inc. reserves the right to make changes in the hardware, packaging and any accompanying documentation without prior written notice.

1:4 Component/Audio Over CAT5 Distribution Amplifier is a trademark of Gefen Inc.

© 2008 Gefen Inc., All Rights Reserved

- 1 Introduction / Operation Notes
- 2 Features
- 3 Panel Description Sender
- 4 Panel Description Receiver
- 5 Connecting the 1:4 Component/Audio Over CAT5 DA
- 6 Operating the 1:4 Component/Audio Over CAT5 DA
- 7 Wiring Diagram
- 8 Network Wiring Diagram
- 9 Specifications
- 10 Warranty

The 1:4 Component/Audio Over CAT5 Distribution Amplifier (DA) sends up to 4 identical sets of sparkling clear component video with audio to remote locations via four CAT5 cables at distances of up to 1000 feet. Now you can reliably and cleanly distribute up to four copies of a video signal with digital or analog audio to remote locations without having to worry about signal drop-off and loss of quality.

How It Works

Simply plug in your component video and audio from your source to the 1:4 Component/Audio DA Sender. Your audio can be analog, digital SPDIF or digital TOSlink. Run your CAT5 cables from the Sender box to up to 4 remote destinations, then connect a receiver box to each CAT5 cable at the terminating end. Attach the displays to the receivers to, power on all equipment, and you should see beautiful video. All audio ports on the receiver will also be active, so even if your source only had analog audio your Component Audio Receiver will have digital and analog audio output. The sender and receiver both will be powered individually by 5V power supplies.

OPERATION NOTES

READ THESE NOTES BEFORE INSTALLING OR OPERATING THE 1:4 COMPONENT/AUDIO OVER CAT5 DA

- Use only industry standard Category-5 Enhanced (CAT5e) cable to operate the 1:4 Component/Audio Over CAT5 DA
- Receiver units are sold individually
- Unit will convert digital audio to analog audio and analog audio to digital audio. It will not however down-mix multichannel digital audio tracks to analog 2 channel. Please see page 5 for additional information
- Both the sending and receiving units must be powered with the supplied power adapters to operate
- Field termination of CAT5e cabling must adhere to the TIA/EIA-568-B specification. Please see page 8 for additional information


Features

- Supports up to 1080p component video
- Supports analog L+R audio and multichannel digital optical or coaxial
- No Loss of Quality
- Plug and play installation
- · Equalization adjustment for different CAT5e skews
- One CAT5e cable for extension


Package Contents - 1:4 Component/Audio Over CAT5 DA Sender

- (1) 1:4 Component/Audio Over CAT5 Distribution Amplifier
- (1) 6 Ft. 3 RCA Component Cable (M-M)
- (1) 6 Ft. RCA Cable (M-M)
- (1) 5V DC 1 AMP Power Supply
- (1) User manual

Component/Audio Receiver - Sold Separately




Back Panel



Front Panel



Back Panel



- 1 Connect the component source into the 1:4 Component/Audio Over CAT5 DA using the provided 3 RCA component cable.
- 2 Connect the audio source to the 1:4 Component/Audio Over CAT5 DA using one of the 3 options below:

Digital Optical - user supplied optical cable Digital Coaxial - supplied SPDIF cable Analog audio - user supplied analog RCA cables

- **3** Connect one CAT5e cable for each component/audio extension (up to 4) from the 1:4 Component/Audio Over CAT5 DA to a Component/Audio Receiver.
- 4 Connect a display to each of the Component/Audio Receivers using a user supplied 3 RCA component cable.
- 5 Connect the audio output of the Component/Audio Receiver to an audio input device using one of the options below:

Digital Optical - user supplied optical cable Digital Coaxial - user supplied SPDIF cable Analog audio - user supplied analog RCA cables

See note below for additional info on audio connectivity.

- 6 Connect the supplied 5V DC power adapters to the 1:4 Component/Audio Over CAT5 DA sender, and one 5V DC power adapter to each Component/Audio Receiver (up to four).
- 7 Power on all monitors first, and then power on the source.

Note: The 1:4 Component/Audio Over CAT5 DA has the ability to convert analog audio signals to digital, and digital audio signals to analog. It will crossconvert any 2 channel audio signal (analog or digital) or pass multi-channel audio directly from the digital inputs to the digital outputs. However, it cannot down-mix digital multichannel audio, such as Dolby Digital and DTS, to the 2 channel analog outputs. Do not attempt to connect the 2 channel analog audio outputs when passing digital multi-channel content. The resulting output will be unrecognizable. Additionally, the 1:4 Component/Audio Over CAT5 DA can cross-convert between digital SPDIF and digital Optical. For example, you can input a digital SPDIF cable on the sender and connect an digital optical cable on the output. Once all cables are connected and all devices are powered on, there is no further operations needed to utilize the 1:4 Component/Audio Over CAT5 DA. However, it may be necessary to tune the signal depending on the quality of CAT5e cabling and distance that the signal has to travel.

<u>Brightness</u>


If the image appears too dim or too bright, adjust the brightness trim pot on the front of the Component/Audio Receiver.


Insert a small flathead device into the brightness trim pot hole and turn the trim pot in either a clockwise or counterclockwise direction. Turn the trim pot in very small increments until the desired brightness is reached.

Focus

If the image is out of focus, or the colors are smeared, adjust the focus trim pot on the front of the Component/Audio Receiver.


Insert a small flathead device into the focus trim pot hole and turn the trim pot in either a clockwise or counterclockwise direction. Turn the trim pot in very small increments until the image clears and there is not blurriness or smearing.





Gefen has specifically engineered their products to work with the TIA/EIA-568-B specification. Please adhere to the table below when field terminating cable for use with Gefen products. Failure to do so may produce unexpected results and reduced performance.

Pin	Color
1	Orange / White
2	Orange
3	Green / White
4	Blue
5	Blue / White
6	Green
7	Brown / White
8	Brown



Category 5 cabling comes in stranded and solid core types. Gefen recommends using solid core cabling.

SPECIFICATIONS

Video Amplifier Bandwidth	350 MHz
Input Video Signal	1.2 Volts p-p
Input Sync Signal	5 Volts p-p (TTL)
Horizontal Frequency Range	15-70 KHz
Vertical Frequency Range	30-170 Hz
Video In/Out	3 RCA component
Audio In/Out	2 RCA Audio, 1 SPDIF, 1 Optical
Link Connector	RJ-45 Shielded
Power Supply	5V DC
Dimensions	8.5"W x 1.6"H x 4.25"D