

RS 232 TO MODULAR ADAPTER

DB 9, DB15 AND DB 25 TO RJ-11/12/45 ADAPTER

The DB 9, DB 15 and DB 25 to RJ-11/12/45 Adapters provide an easy way to use inexpensive 4 or 6-wire RJ-11, or 8-wire RJ-45 telephone cable to interconnect computer equipment with DB 9, DB 15 or DB 25 interfaces.




6 C or 4 C



8 C

Function	Description	Part no.
DB 25 Male/RJ-11 4-wire	DB25 to RJ-11 Adapter	IMA 257
DB 25 Female/RJ-11 4-wire	DB25 to RJ-11 Adapter	IMA 258
DB 25 Male/RJ-12 6-wire	DB25 to RJ-12 Adapter	IMA 253
DB 25 Female/RJ-12 6-wire	DB25 to RJ-12 Adapter	IMA 254
DB 25 Male/RJ-45 8-wire	DB25 to RJ-45 Adapter	IMA 251
DB 25 Female/RJ-45 8-wire	DB25 to RJ-45 Adapter	IMA 252



6 C or 4 C



8 C

Function	Description	Part no.
DB 15 Male/RJ-11 4-wire	DB 15 to RJ-11 Adapter	IMA 267
DB 15 Female/RJ-11 4-wire	DB 15 to RJ-11 Adapter	IMA 268
DB 15 Male/RJ-12 6-wire	DB 15 to RJ-12 Adapter	IMA 263
DB 15 Female/RJ-12 6-wire	DB 15 to RJ-12 Adapter	IMA 264
DB 15 Male/RJ-45 8-wire	DB 15 to RJ-45 Adapter	IMA 261
DB 15 Female/RJ-45 8-wire	DB 15 to RJ-45 Adapter	IMA 262



6 C or 4 C



8 C

Function	Description	Part no.
DB 9 Male/RJ-11 4-wire	DB 9 to RJ-11 Adapter	IMA 277
DB 9 Female/RJ-11 4-wire	DB 9 to RJ-11 Adapter	IMA 278
DB 9 Male/RJ-12 6-wire	DB 9 to RJ-12 Adapter	IMA 273
DB 9 Female/RJ-12 6-wire	DB 9 to RJ-12 Adapter	IMA 274
DB 9 Male/RJ-45 8-wire	DB 9 to RJ-45 Adapter	IMA 271
DB 9 Female/RJ-45 8-wire	DB 9 to RJ-45 Adapter	IMA 272

