


7045700 SIDE

530JBK-2T-30R3G
- 4885H
(4885G)

CABLE +
CONNECTOR



1	2	3	4	5	6	7	8	9
Y	R	G	Y	R	G	G	R	Y
POT AXIS	X	↑	POT AXIS	Z	G	POT AXIS	Y	↔

Resistance	Resistance	Resistance
1-3 pin	4-6 pin	7-9 pin
= 10KΩ	= 10KΩ	= 10KΩ


Joystick Regulation Range

4KΩ - 6KΩ	4KΩ - 6KΩ	4KΩ - 6KΩ
-----------	-----------	-----------

DRAWING No. 100

30JBK-ET-30R3G
10K

TOUCH
SIDE



Y - Yellow
R - Red
G - Green
W - White
(Center Tap)


Resistance	Resistance	Resistance
POT-X	POT-Z	POT-Y
Yellow	Yellow	Yellow
POT-X	POT-X	POT-X
Green	Green	Green
10KΩ	10KΩ	10KΩ

TOUCH Regulation Range
0-10KΩ 0-10KΩ 0-10KΩ

DRAWING 200

S303BK-2T-30R3G
2K

704STICK
SIDE




	Resistance	Resistance	Resistance
Y - Yellow	POT-X	POT-Z	POT-Y
R - Red	Yellow	Yellow	Yellow
G - Green	POT-X	POT-Z	POT-Y
	Green	Green	Green
W - White (Center Tap)	2KΩ	2KΩ	2KΩ

704stick Regulation Range

0-2KΩ 0-2KΩ 0-2KΩ

DRAWING 201

104574
SIDE



S 303BK-2T
-30036-2K

PLS ADD
6 x Resistor
3.8k (4k)
on Yellow &
Green cable
only
W - cable
(center top)
No connected.

AFTER
(CHANGE)

Resistance	Resistance	Resistance
1-3 Pin	4-6 Pin	7-9 Pin
10k Ω	10k Ω	10k Ω

704stick Regulation Range
4k Ω -6k Ω 4k Ω -6k Ω

PLS ADD
JST CONNECTOR

4k Ω -6k Ω

DRAWING 202

TOYSTICH
SIDE


2K

2K

2K

5303HK-2T

-30R36 2K



1	2	3	4	5	6	7	8	9
Y	R	G	Y	R	G	G	R	Y
POT AXIS X	↑↓		POT AXIS Z	G		POT AXIS Y	↔	

Resistance	Resistance	Resistance
POT-X	POT-Z	POT-Y
Yellow	Yellow	Yellow
POT-X	POT-Z	POT-Y
Green	Green	Green
2KΩ	2KΩ	2KΩ


TOYSTICH Regulation Range

0-2KΩ 0-2KΩ 0-2KΩ

DRAWING 304

CABLE

CABLE



5303H4-2T
-3003G 2k

PLS ADD
6x Resistor 3k (4k)
on yellow &
green cable only

← PLS ADD

35T CONNECTOR

AFTER
CHANGE

Resistance	Resistance	Resistance
1-3pin	4-6pin	7-9pin
10k	10k	10k

Joystick regulation range
4k-6k 4k-6k 4k-6k

DRAWING 302